





specifications

pattern	avant    
content	contract vinyl
weight	37.0 +/- 1.0 oz per linear yard
width	54"
protective finish	advanced soil and stain resistant top coat
abrasion resistance	exceeds 250,000 double rubs (heavy duty / CFFA-1)
flammability*	california technical bulletin 117, section e cid-a-a-2950-a (formerly ccc-a-680a) boston fire code-test BFD IX-1 port authorities of NY and NJ faa far 25.853 (b) bifma class a

performance / properties

superior abrasion resistance
antimicrobial / bacterial resistant
mildew resistant
sulfide / urine stain resistant
oil resistant
uv stabilized pigments

cleaning and maintenance

for easy cleaning of recent soiling, promptly wash with a mild soap solution.
for a previously soiled area that has not yet penetrated the vinyl surface, scrub
with a soft brush using a mild, non-abrasive cleaner.

cleaning frequency depends on use. please clean and maintain your furniture regularly.

clean all stains as quickly as possible and use the following cleaning procedures
in order for best results.

- step 1** remove any excess spills with damp cloth. clean with a mild liquid
soap and water mixture. rinse with clear water and dry.
- step 2** use straight application of concentrated cleaners such as formula 409®
or fantastik®. rinse with clear water. wipe with clean cloth.
- step 3** for more difficult stains, use a 6% mixture of bleach with water. rinse
with clear water and dry. never use bleach in full strength to clean vinyl.

notes please be sure to use a soft brush or cloth saturated with cleaning material.
always test cleaning methods on an inconspicuous area of furniture.
if stain persists, stain probably has set. although this vinyl is resistant to
most common stains, some fabric dyes and ballpoint inks can create a
permanent stain.

caution some solvents are highly flammable. exercise proper care in cleaning.
this information is not a guarantee and does not relieve the user from the
responsibility of the proper and safe use of this vinyl and all cleaning agents.

formula 409® is a registered trademark of the clorox company.
fantastik® is a registered trademark of s.c. johnson & son, inc.

dye lots may vary slightly from samples shown.

*this term and any corresponding data refer to typical performance in the tests indicated and should not be construed to imply
the behavior of this or any other material under actual fire conditions.

